

SAVE THESE INSTRUCTIONS

1. Enter your ComfortSeries™ walk-in bathtub, and close the door. *Do not put weight on the door when entering and exiting the tub.*



2. Outward Opening Door: Ensure you LOCK the door by moving lever arm to the “locked” position (away from you). **Do not apply excessive pressure when placing the handle in the closed/locked position.**



3. Inward Opening Door: Place the handle in the “down” position (away from you). **Do not apply excessive pressure when placing the handle in the closed/locked position.**

4. Fill the bath to at least 2 inches above the highest jet before activating the whirlpool pump.



5. Your ComfortSeries™ walk-in bathtub is equipped with both Jet Massage and Air Massage. All operations are controlled with the Electronic Touchpad Control. The pump or blower is operated by the buttons “Jets” and “Air”. It may take a few seconds for the jets to activate.



6. Whirlpool Jet flow can be adjusted by turning the “Legs-only Massage” valve located below the safety grab bar.



7. The “Legs-only Massage” opens and closes the jets above the seat, which allows you to fill the tub half-way and operate only the lower whirlpool jets. The “Legs-only Massage” valve **must** be closed when filling the tub half-way and operating the whirlpool. Failure to close the valve when filling the tub half-way will result in water shooting out of the jets above the seat when the pump is activated.



AIR

8. Your ComfortSeries™ walk-in bathtub is equipped with Air Massage. You can activate the heated blower by pressing “Air” on the Electronic Touchpad Control. Push the button to turn on/off, and to cycle for various speeds.



JETS

9. Your ComfortSeries™ walk-in bathtub is equipped with an In-Line Heater. The heating element will be turned on automatically by pressing “Jets” on the Electronic Touchpad Control. This heater is designed to maintain water temperature and extend comfortable bathing time, but does not reheat the bath water.



10. Your ComfortSeries™ walk-in bathtub is equipped with the Automatic Ozone Tub Clean System. This system will turn on automatically when the whirlpool system is turned on.



LIGHTS

11. Your ComfortSeries™ walk-in bathtub is equipped with Chromatherapy Lights. You can activate the lights by pressing “Lights” on the Electronic Touchpad Control. Push the button to turn on/off, and to cycle through and change the colour of the lights.



12. Your ComfortSeries™ walk-in bathtub is equipped with Aromatherapy. Place whole sachet of aromatherapy beads (do not empty sachet) in the reservoir located near the back on the tub deck, and replace the lid. Scents are activated when the Air Massage blower is turned on.



13. Your ComfortSeries™ walk-in bathtub is equipped with the QuickDrain®. This system has its own dedicated pump, suction and switch to activate the drain. Open the traditional drain system first by turning the overflow clockwise. Press “Drain” on the Electronic Touchpad Control to activate QuickDrain®. When the water falls below the suction guard, press “Drain” again on the Electronic Touchpad Control to turn drain system off.



DRAIN

14. Both the whirlpool and air spa systems are designed so that water will drain from the plumbing after each use.

- All Air Systems are equipped with a purge cycle to remove residual water from the lines. The purge cycle will begin approximately 20 minutes after the unit is initially turned off, and will continue for several minutes. Do not be alarmed when the cycle begins. The purge will automatically turn off when purge is complete.
- There are no user-serviceable parts located under the tub.
- If tub has outward-opening door, the bottom panel beneath the door may be removed to accommodate the rolling legs of a hydrolic patient lift (if used to transfer bather).

DO NOT use bubble bath or Epsom salts when any pumps are operating. Bath oils may be used, however their use will require more frequent cleaning of the whirlpool and air spa system.